

Easy to fit:

15-Minute Installation

Required tools: Drill motor, 1/4" (6 mm) drill bit, Phillips-head screwdriver, 7/16" (11 mm) spanner or adjustable spanner.

1. Slip each Hydrofoil over the cavitation plate directly above your propeller. Place the lines facing up. Then drill 1/4" (6 mm) holes through the foil. The plate can be drilled from above or below, depending on available room for the drill motor. In some instances, a right angle drill chuck may be needed.
2. Remove each foil and clean up the plastic and metal shavings. Slip each foil onto the cavitation plate again and insert fasteners supplied (the nylon locking nuts go on top). Tighten snugly. Do not over tighten. Sealant is not required although it's nice to have on there so the bolts don't vibrate loose over an extended period of time.

